

# FLOOR PAD CROSS REFERENCE CHART

MICROTRON "Polyline/Valuline"	3M "Scotchbrite"	AMERICAN "Thickline"	ETC "Gorilla"	GLIT "Thickline"	NORTON "Beartex"	PUREX "Brillo"
Ultra 66/ Super Strip	High Productivity Stripping Pad	Heavy Duty Stripper HP500	Razorback	High Performance Stripping	High Performance Stripping	N-29 High Performance Stripping
VL Black Strip	Thickline Black	Black Strip	Black Strip	Thickline Black	Super 54 Black Strip	V32 Syndisc Black
PL Brown Strip	Type 51 Brown	Brown Strip	Brown Strip	Thickline Brown	Super 54 Brown Strip	V36 Brown Strip
VL Green Scrub	Thickline Green	Green Scrub	Green Scrub	Thickline Green Scrub	Super 54 Green Scrub	V30 Syndisc Green
PL Blue Scrub	Type 51 Blue	Blue Cleaner	Blue Cleaner or Orange Monster	Thickline Blue Cleaner	Super 54 Blue Clean	V35 Blue Scrub
VL T-Gray Scrub	—	—	—	Light Blue Cleaner	—	—
PL Regular Red	Type 51 Red Buffer	Red Spray Buff	Reg. Red Spray	Thickline Red	Super 54 Red	V34 Red Buff
PL 40-D Red	—	Red High Gloss	Red Supergloss	High Speed Coral	Super 54 Special Red Buffer	—
VL Natural Fiber Buff	—	Porko High Speed Spray Buff	Gorilla	Buckaroo	Special Red Buffer	V43 The Natural
VL Tan Buff	Thickline Tan	Tan Buffing	Tan Buff	Thickline Tan Polish	Grizzly Bear	V31 Syndisc Tan Buff
PL Natural Poly Burnish	—	—	—	Jackaroo	—	—
PL 100-D Polythermal	Topline Preburnish	—	—	—	—	—
PL Yellow High Speed	Topline Speed Burnish	Yellow High Speed	Gold High Speed	High Speed Yellow or Peach	—	V45 Gold
VL UHS Tan	Ultra H/S Tan	—	—	High Speed Peach	—	—
PL Beige Polythermal	Super H/S Beige	Beige Ultra High Speed	White Rubberized Super Speed	Champagne Burnish	Champagne	V44 Beige
UHS Gray Burnish	—	COMBO	—	—	—	—
UHS Aqua Burnish	Ultra H/S Aqua	—	—	JOEY	—	—
UHS Natural Light	Topline Natural Blend	—	Gorilla Lite	Jackson Light	—	—
PL White Polish	Type 51 White Polish	White Polish	White Super Polish	White Super Polish	Super 54 White Gloss	V33 White
Thinline 1/4"	—	Thinline	Thin 1/4"	Thinline	"14Line"	—
Sandscreen	Scotch Mesh	Sandscreen	Sandscreen	Sandscreen	Screenpak Durite	—

FLOOR PADS

# WHAT FLOOR PAD TO RECOMMEND

Application	RPM of Machine	Chemical/Wet or Dry	Pad Recommendations	Results
<b>STRIPPING</b>	185-350	Strip Solution / Wet	<ol style="list-style-type: none"> <li>1. <b>Black Strip</b></li> <li>2. <b>Ultra 66 Super Strip</b> - most aggressive</li> <li>3. <b>Brown Strip</b> - less aggressive (Dry stripping)</li> </ol>	Removal of all finish, wax build-up and dirt down to the original surface.
<b>SCRUBBING</b>	185-350	Cleaner / Wet	<ol style="list-style-type: none"> <li>1. <b>Green Scrub</b> or <b>Blue Scrub</b></li> <li>2. <b>Gray Scrub</b> - less aggressive</li> <li>3. <b>Regular Red Spray Buff</b> - for "Automatic Scrubbers"</li> </ol>	Thoroughly clean all dirt and some finish from heavily soiled floors.
<b>SPRAY BUFFING</b>	185-350 350 - 1200 1200+	Spray Buff Solution/ Wet	<ol style="list-style-type: none"> <li>1. <b>Regular Red Spray Buff</b></li> <li>1. <b>Red 40-D</b></li> <li>2. <b>Yellow High Speed</b></li> <li>1. <b>100-D Neutral Polythermal</b></li> </ol>	Spray buff solution will clean when wet and shine when dry. Sometimes called "Restoring" the finish.
<b>BUFFING</b>	185-350 350 - 1200	Dry or light water mist	<ol style="list-style-type: none"> <li>1. <b>White Polish</b> - for higher gloss</li> <li>2. <b>Tan Buff</b> or <b>Natural Fiber Buff</b></li> <li>1. <b>Red 40-D</b></li> <li>1. <b>Natural Lite</b></li> </ol>	Polishing a clean dry floor. Upgrading the finish quality after scrubbing or spray buffing.
<b>BURNISHING</b>	Propane Machines (1500-300)	Dry	<ol style="list-style-type: none"> <li>1. <b>Beige Polythermal</b> - for softer finishes</li> <li>2. <b>Ultra High Speed Tan Buff</b> - for harder finishes</li> <li>3. <b>Natural Poly Burnish</b> - for most aggressive burnishing</li> </ol>	Applying heat and friction using ultra high speed machines to produce a "high" shine and harden the finish. "Levels" the finish.
	Electric+Battery Machines (1500-300)	Dry	<ol style="list-style-type: none"> <li>1. <b>Ultra High Speed Tan Buff</b> - for medium to hard finishes</li> <li>2. <b>Ultra High Speed Aqua</b> - for softer finishes</li> <li>3. <b>Natural Fiber Buff &amp; Burnish</b> - also works well on most finishes</li> </ol>	

These are good starting recommendations. Because of the vast differences in finishes, machines and operator techniques, results may vary. Please call MICROTRON ABRASIVES for additional information 1-800-476-PADS.